

FIG. 1




FIG.2





FIG.3



10073007.024202

FIG. 4




FIG.5

58

	SSP NAME	VALID BIT	IP ADDRESS	VOLUME NUMBER
IN-USE STORAGE APPARATUS				
		:	:	:
MIGRATION DESTINATION STORAGE APPARATUS				
		:	:	:

10073007-021202

FIG.6

A graphical user interface window, labeled 120, is shown. It contains a title bar at the top, labeled 125. Below the title bar is a message box that reads: "PLEASE INPUT THE SSP NAME, THE IP ADDRESS, AND THE VOLUME NUMBER OF AN SSP THAT YOU USE AT PRESENT." Below the message box are three input fields stacked vertically: "SSP NAME" (labeled 121), "IP ADDRESS" (labeled 122), and "VOLUME NUMBER" (labeled 123). At the bottom of the window are two buttons: "OK" (labeled 128) and "CANCEL" (labeled 129).

10073007-021202

FIG. 7

10073007.021202

130

REQUEST PROPERTY SELECTING FRAME

131 ☐ OF LOWER PRICE

132 ☐ OF HIGHER PERFORMANCE

133 ☒ OF HIGHER RELIABILITY

139 RETRIEVAL

COMPARISON RESULT DISPLAYING FRAME

	SSP NAME	PERFORMANCE	COST	RAID LEVEL	MIRROR CONFIGURATION	BACK-UP INTERVAL
IN USE	SSP30a	100ms	\$100/GB	5	ABSENT	168h
CANDIDATE	<input type="radio"/> SSP30b	50ms	\$200/GB	1	PRESENT	24h
	<input checked="" type="radio"/> SSP30c	200ms	\$50/GB	5	PRESENT	24h

140

141

142

DECISION MAKING FRAME

WRITTEN-CONTRACT DISPLAYING FRAME

OK

CANCEL

150

151

152

159

FIG.8




FIG.9




FIG.10





FIG.11



10072007.621202

FIG.12






FIG.13



10073007.021202

FIG.14



10072007-021202